Customer Support:
Tel: 1-347-492-4014
Email: info@PureEffectFilters.com
www.PureEffectFilters.com

Thank you for your purchase of our Premium-Quality, Advanced Filtration Cartridges, Made in USA.

INSTALLATION INSTRUCTIONS

Please Inspect cartridges for any shipping damage, **if damage is found, do not remove shrink wrapping**, notify us promptly for replacement.

Unpack (Remove shrink wrap) and insert the **SuperBlock™** Cartridge into **Chamber # 1** and **AntiRad-Plus™** Cartridge into **Chamber #2** with Rubber Ring (Gasket) facing down for countertop systems & facing up for undercounter systems. Close the chambers by hand so as to not overtighten. Let the system run for 10 minutes with cold water.

Note: Water may be cloudy during for about a week as the natural minerals in the cartridges adapt, to speed the adaptation period up, turn the system on 15-20 seconds at a time more often throughout the day. Do not flush for longer periods, as it won't be as effective and will waste cartridge life.

IMPORTANT! – PLEASE ENSURE CARTRIDGES ARE INSERTED IN CORRECT ORDER!

