

**Thank you for your purchase of the  
ULTRA & ULTRA-UC REPLACEMENT CARTRIDGE SET**


**IMPORTANT!** – The “This End Up” marking on the AntiRad-Plus<sup>TM</sup> cartridge only applies to undercounter systems, for countertop systems this end must be facing down.

**CAUTION!** - For undercounter systems, please ensure you have turned off the water supply at the cold-water line & opened the dedicated faucet (to release pressure) before servicing system. If you have our Leak-Stopper Device Installed, ensure to protect it from getting wet during this process.

**CARTRIDGE CHANGE INSTRUCTIONS**

1.  Remove old cartridges, clean housings with dish soap and rinse w/cool-warm water.  
*Recommended: Dry & Lubricate the black O-rings inside housings (not cartridges) w/ Food-Grade Silicone only. (Available on our “Parts” page).*
2.  If you have our **Gallon-Meter**: Set it to **500** Gallons (see its instructions).
3.  Remove shrink wrap from the new cartridges and insert them as per next step.
4.  Place **SuperBlock<sup>TM</sup>** Cartridge into **Chamber #1 (Input side)** & **FluorSorb-MAX<sup>TM</sup>** into **Chamber #2 (Middle)**. Close **Chamber #3 empty** & run the system for **5** minutes.
5.  Place **AntiRad-Plus<sup>TM</sup>** Cartridge into **Chamber #3 (Output side)**, Flush for **10** min.

*\*Check for leaks. Water may be cloudy for apx. 1-2 weeks as the natural minerals adapt, this is a harmless & temporary effect. To speed this up, run the system more often throughout the day in 15-20 second bursts (this is better than leaving it on long, which wastes cartridge life). **\*\*If you are storing the set for later, please ensure there are no punctures or holes in the shrink-wrapping, if so, place in ziplock bags to isolate from air.***



# UNDERCOUNTER SYSTEM INSTALLATION DIAGRAM

(For reference & verification)

